

# Samsung Voicemail Message Playback

Press

1	Play message
2	Play previous message
3	Delete message
4	Reply to sender (internal msg only)
5	Place call to sender (internal caller only)
6	Forward a copy of the message
7	Rewind 5 seconds
77	Change playback volume
8	Pause-Resume playback of message
9	Fast forward 5 seconds
99	Change playback speed
#	Skip to next message
##	Scan messages (first 7 seconds of each msg)
0	Play menu options
00	Play message information
*	Cancel, return to subscriber menu